

TCI 710 HD VEHICLE WASH APPLICATION PROCEDURE

- 1. APPLY THIN FILM OF PREPORTIONED SOLUTION FROM BOTTOM TO TOP USING SPRAY CHEMICAL APPLICATOR.**
- 2. POWERWASH WITH 2000-3000 PSI COLD WATER FROM BOTTOM TO TOP.**
- 3. RINSE FROM TOP DOWN.**

DO NOT APPLY DIRECTLY TO HOT METAL SURFACES

DO NOT USE HOT WATER (ABOVE 100 DEG)

DO NOT ALLOW CHEMICAL TO DRY

**DO NOT APPLY CHEMICAL THROUGH THE
PRESSURE WASHER**

For Technical Assistance Call

Chem  Wash

(316) 744-SOAP